

FLORATECH[®] ASIA
 6 FL., No. 360, RUEI GUANG ROAD
 NEIHU, TAIPEI, TAIWAN, ROC
 PHONE: 886 2 8751 6060
 FAX: 886 2 8751 6363

FLORATECH[®] AMERICAS
 291 EAST EL PRADO COURT
 CHANDLER, ARIZONA 85225
 PHONE: 480-545-7000
 FAX: 480-892-3000

FLORATECH[®] EU
 VIA TANARO 15, 20017 RHO
 MILAN, ITALY
 PHONE: 39 02 93 04946
 FAX: 39 02 93 50 8238

see www.floratech.com to find your local Floratech representative

Moisturizing Moringa Slipstick

Product highlighted: Floralipids[®] Moringa Oil, Floraesters[®] 70

Floralipids Moringa Oil helps to wet and disperse the pigments (dries) in this lipstick, yielding a smoother, more even coverage to the lipstick. Floralipids Moringa Oil provides high slip to the stick. This shade does not exhibit syneresis.

Phase	Trade Name	INCI Name	Supplier	%wt./wt
A.	Crystal O	Ricinus Communis (Castor) Seed Oil	CasChem	Q.S.
	Floralipids Moringa Oil, Refined	Moringa Oleifera Seed Oil (and) Tocopherol	Floratech	15.0
	Floraesters 70	Jajoba Esters	Floratech	1.0
	Carnauba Wax #1 Yellow SP 63	Copernicia Cerifera (Carnauba) Wax	Strahl & Pitsch	4.0
	Candelilla Wax SP 75	Euphorbia Cerifera (Candelilla) Wax	Strahl & Pitsch	5.0
	Yellow Beeswax SP 6P	Beeswax	Strahl & Pitsch	3.5
	Microcrystalline Wax SP 18	Microcrystalline Wax	Strahl & Pitsch	4.0
	Preservative CAB-O-SIL M-5	----- Silica	Cabot	Q.S. 0.2
B.	Crystal O	Ricinus Communis (Castor) Seed Oil	CasChem	13.0
	Arlacel P-100	Polyhydroxystearic Acid	Uniqema	0.5
	Titanium Dioxide 10-34-PC-0748	Titanium Dioxide	Lubrizol	5.5
	Pur Oxy Red B.C. 34-3511	Iron Oxides	Lubrizol	4.0
	D&C Red 30 Talc Lake 10-31-DA-3130	Red 30 Lake	Lubrizol	2.5
	FD&C Blue No. 1 Aluminum Lake	Blue 1 Lake	Sensient Food Colors	0.1
	Pur Oxy Black B.C. 34-3068	Iron Oxides	Lubrizol	0.5
C.	Covi-Ox T-70	Tocopherols	Cognis	0.1
			TOTAL	100.00

Mixing Procedure:

1. Combine ingredients of Phase A and heat to 85°C with moderate agitation.
2. Combine Phase B and pass 2 times through a 3-roll mill. Add Phase B to Phase A with propeller agitation.
3. Cool batch to 75°C, add Phase C and mix with propeller agitation. Fill mold as soon as possible.

Note: The information herein is based on our research and the research of others and is believed to be accurate. No guarantee of their accuracy is made and the products discussed are sold without warranty, expressed or implied, and upon condition that purchasers shall make their own tests to determine the suitability of such products for their particular purposes. Likewise, statements concerning the possible use of these products are not intended as recommendations to use these products in infringement of any patent.