

FLORATECH[®] ASIA
6 FL., NO. 360, RUEI GUANG ROAD
NEIHU, TAIPEI, TAIWAN, ROC
PHONE: 886 2 8751 6060
FAX: 886 2 8751 6363

FLORATECH[®] AMERICAS
291 EAST EL PRADO COURT
CHANDLER, ARIZONA 85225
PHONE: 480-545-7000
FAX: 480-892-3000

FLORATECH[®] EU
VIA TANARO 15, 20017 RHO
MILAN, ITALY
PHONE: 39 02 93 04946
FAX: 39 02 93 50 8238

see www.floratech.com to find your local Floratech representative

Rainbow Magic Moisturizing Gel

Products highlighted: Florasolvs[®] PEG-16 Macadamia, Metasomes[®] with Glitter

This formula produces a clear moisturizing gel to apply on the skin. Metasomes provide an unexpected, festive explosion of sparkle to the skin.

Phase	Trade Name	INCI Name	Supplier	%wt./wt.
A.	Deionized Water	Water		Q.S.
	Versene Na2	Disodium EDTA	Dow	0.01
	Carbopol Ultrez 10	Carbomer	Lubrizol	0.25
B.	Florasolvs PEG-16 Macadamia	PEG-16 Macadamia Glycerides	Floratech	2.00
C.	Preservative	-----		Q.S.
D.	Triethanolamine 99%	Triethanolamine	Dow	0.40
	Deionized Water	Water		1.50
E.	Color (optional)	-----		Q.S.
F.	Metasomes-20% Glitter^{1,2}	Petrolatum (and) Polyethylene (and) Ethylhexyl Palmitate (and) Polyethylene Terephthalate (and) Acrylates Copolymer	Floratech	2.0
			TOTAL:	100.00

Mixing Procedure:

1. Dissolve Versene Na2 in water at room temperature, then disperse carbomer in water with rapid propeller agitation for 30 minutes to an hour.
2. Add Phase B to Phase A with rapid agitation and mix until uniform.
3. Add Phase C to Phase AB and mix until uniform with medium propeller agitation.
4. Mix Phase D, then slowly add to Phase ABC. Mix until gel is uniform.
5. With sweep agitation, slowly add Phase E to Phase ABCD until gel color is uniform.
6. Add Phase F to completed mixture with sweep agitation until Metasomes are evenly distributed throughout gel.

¹ Glitter supplied by Meadowbrook Inc.

² Any color or combination of colors, standard size and playtime.

Note: The information herein is based on our research and the research of others and is believed to be accurate. No guarantee of their accuracy is made and the products discussed are sold without warranty, expressed or implied, and upon condition that purchasers shall make their own tests to determine the suitability of such products for their particular purposes. Likewise, statements concerning the possible use of these products are not intended as recommendations to use these products in infringement of any patent.