

FLORATECH® ASIA
 6 FL., NO. 360, RUEI GUANG ROAD
 NEIHU, TAIPEI, TAIWAN, ROC
 PHONE: 886 2 8751 6060
 FAX: 886 2 8751 6363

FLORATECH® AMERICAS
 291 EAST EL PRADO COURT
 CHANDLER, ARIZONA 85225
 PHONE: 480-545-7000
 FAX: 480-892-3000

FLORATECH® EU
 VIA TANARO 15, 20017 RHO
 MILAN, ITALY
 PHONE: 39 02 93 04946
 FAX: 39 02 93 50 8238

see www.floratech.com to find your local Floratech representative

Castor Oil-Free Exfoliate Lip Treatment

Products highlighted: Florasun® 90, Floramac® Macadamia Oil, Floraesters® 30, Floraesters 70, Florabeads® Jojoba

Florasun 90, Floramac Macadamia Oil and Floraesters are as stable as castor oil, and offer an interesting marketing concept. Florabeads Jojoba incorporated in this treatment formula act as an excellent lip exfoliator.

Phase	Trade Name	INCI Name	Supplier	%wt./wt.
A.	Florasun 90	Helianthus Annuus (Sunflower) Seed Oil (and) Tocopherol	Floratech	11.5¹
	Floramac Macadamia Oil	Macadamia Integrifolia Seed Oil (and) Tocopherol	Floratech	26.6
	Floraesters 30	Jojoba Esters (and) Tocopherol	Floratech	21.0
	Floraesters 70	Jojoba Esters	Floratech	1.2
	Carnauba Wax #1 Yellow SP 63	Copernicia Cerifera (Carnauba) Wax	Strahl & Pitsch	4.9
	Candelilla Wax SP 75	Euphorbia Cerifera (Candelilla) Wax	Strahl & Pitsch	6.0
	Yellow Beeswax SP 6P	Beeswax	Strahl & Pitsch	4.2
	Microcrystalline Wax SP 18	Microcrystalline Wax	Strahl & Pitsch	4.9
	Indopol H-100	Polybutene	Amoco	6.0
	Preservative CAB-O-SIL M-5	----- Silica	Cabot	Q.S. 0.6
B.	Covi-Ox T-70	Tocopherol	Cognis	0.12
	Fragrance (optional)	Fragrance		Q.S.
C.	Florabeads Jojoba 28/60²	Jojoba Esters	Floratech	10.00
			TOTAL:	100.00

Mixing Procedure:

1. Combine ingredients of Phase A and heat to 85°C with moderate agitation.
2. Cool Phase A to 75°C, add Phase B and mix with propeller agitation.
3. Cool to 70°C and add Phase C. Fill containers as soon as possible.

¹ Amount based on use of 1% preservative and 2% fragrance. Adjust accordingly if different amounts are used.

² Any color or combination of colors.

Note: The information herein is based on our research and the research of others and is believed to be accurate. No guarantee of their accuracy is made and the products discussed are sold without warranty, expressed or implied, and upon condition that purchasers shall make their own tests to determine the suitability of such products for their particular purposes. Likewise, statements concerning the possible use of these products are not intended as recommendations to use these products in infringement of any patent.