

FLORATECH[®] ASIA
 6 FL., No. 360, RUEI GUANG ROAD
 NEIHU, TAIPEI, TAIWAN, ROC
 PHONE: 886 2 8751 6060
 FAX: 886 2 8751 6363

FLORATECH[®] AMERICAS
 291 EAST EL PRADO COURT
 CHANDLER, ARIZONA 85225
 PHONE: 480-545-7000
 FAX: 480-892-3000

FLORATECH[®] EU
 VIA TANARO 15, 20017 RHO
 MILAN, ITALY
 PHONE: 39 02 93 04946
 FAX: 39 02 93 50 8238

see www.floratech.com to find your local Floratech representative

Squeeze Tube Lip Balm

Product highlighted: Floraesters[®] K-100 Jojoba, Floraesters IPJ, Floraesters 70, Floraesters Jojoba Oil, Floramac[®] Macadamia Oil

Phase	Trade Name	INCI Name	Supplier	% wt./wt.
A.	Snow White Petrolatum	Petrolatum	Penreco	53.2
	Floraesters K-100 Jojoba	Hydrolyzed Jojoba Esters (and) Jojoba Esters (and) Water (Aqua)	Floratech	9.0
B.	Lanette 16	Cetyl Alcohol	Cognis	2.3
	Beeswax, Yellow Refined SP-6	Beeswax	Strahl & Pitsch	3.8
	Carnauba Wax #1	Copernicia Cerifera (Carnauba) Wax	Strahl & Pitsch	1.2
	Ozokerite Wax White SP 1026	Ozokerite	Strahl & Pitsch	1.2
	Floraesters 70	Jojoba Esters	Floratech	3.0
	Floraesters IPJ	Isopropyl Jojobate (and) Jojoba Alcohol (and) Jojoba Esters (and) Tocopherol	Floratech	7.5
	Floraesters Jojoba Oil Refined Floramac Macadamia Oil	Simmondsia Chinensis (Jojoba) Seed Oil Macadamia Integrifolia Seed Oil (and) Tocopherol	Floratech Floratech	1.5 1.5
Microcrystalline Wax SP 18	Microcrystalline Wax	Strahl & Pitsch	6.0	
Lexol GT-865	Caprylic/Capric Triglyceride	Inolex	2.3	
C.	Parsol MCX	Ethylhexyl Methoxycinnamate	Hoffman-La Roche	3.5
	Esalol 567	Benzophenone-3	Int'l Specialty Products	1.3
	Camphor Gum	Cinnamomum Camphora	Belmay	1.8
	l-Menthol	Menthol	Symrise	0.9
			TOTAL:	100.00

Mixing Procedure:

1. Combine ingredients of Phase A and mix with stirring rod.
2. Add ingredients of Phase B to Phase A individual by one while heating to 105°C. Blend with slow propeller agitation until homogenous at 105°C for 10 minutes.
3. Slowly cool to 75-80°C with no agitation to allow any foam to dissipate. Blend in ingredients of Phase C one at a time with stirring rod to avoid air bubbles. Fill tubes at around 70°C.

Note: The information herein is based on our research and the research of others and is believed to be accurate. No guarantee of their accuracy is made and the products discussed are sold without warranty, expressed or implied, and upon condition that purchasers shall make their own tests to determine the suitability of such products for their particular purposes. Likewise, statements concerning the possible use of these products are not intended as recommendations to use these products in infringement of any patent.